

# RIDING BOOT TREES

## FITTING CHART

The size of a riding boot tree is denoted by the foot size and the girth of your calf at it's widest point. So if you were a Men's size 9 with a calf size of 365mm you would need to order a Size: Small with a Girth: Narrow.

### WOMENS:

BOOT FITTING NARROW				BOOT FITTING STANDARD				BOOT FITTING WIDE			
TREE SIZE	GIRTH		BOOT SIZE	TREE SIZE	GIRTH		BOOT SIZE	TREE SIZE	GIRTH		BOOT SIZE
	MINIMUM	MAXIMUM			MINIMUM	MAXIMUM			MINIMUM	MAXIMUM	
SN	302mm	352mm	3	SN	302mm	352mm	3	SS	336mm	386mm	3
SN			4	SS	336mm	386mm	4	SS			4
SM/SS			5	SS			5	SS			5
MN	323mm	373mm	6	MN	323mm	373mm	6	MS	362mm	412mm	6
MN			7	MS	362mm	412mm	7	MS			7
MS	362mm	412mm	8	MS			8	MS			8

### MENS:

BOOT FITTING NARROW				BOOT FITTING STANDARD				BOOT FITTING WIDE			
TREE SIZE	GIRTH		BOOT SIZE	TREE SIZE	GIRTH		BOOT SIZE	TREE SIZE	GIRTH		BOOT SIZE
	MINIMUM	MAXIMUM			MINIMUM	MAXIMUM			MINIMUM	MAXIMUM	
MN	323mm	373mm	7	MN	323mm	373mm	7	MS	362mm	412mm	7
MN			8	MS	362mm	412mm	8	MS			8
LN	345mm	395mm	9	LN	345mm	395mm	9	LS	375mm	425mm	9
LN			10	LS	375mm	425mm	10	LS			10
LN			11	LS			11	LS			11

Key to Tree sizes:

SN = Small Narrow  
 MN = Medium Narrow  
 LN = Large Narrow

SS = Small Standard  
 MS = Medium Standard  
 LS = Large Standard